


Model: PM-D750, Stylus Photo R300/310  
 Board: C536PSB  
 Rev. : C  
 Sheet: 1/1



Model: Stylus Photo R300/310  
 Board: C536PSE  
 Rev. : D  
 Sheet: 1/1